

Timy

Programm

Training




ALGE
T I M I N G

Table of contents

1	Keyboard	3
2	Getting started	4
<u>2.1</u>	<u>Turn ON-OFF</u>	<u>4</u>
2.1.1	Turn on	4
2.1.2	Turn off	4
<u>2.2</u>	<u>Menu</u>	<u>4</u>
3	Programs	5
<u>3.1</u>	<u>Impulse-Counter</u>	<u>5</u>
3.1.1	Program depending settings.....	5
3.1.2	System-sketch	6
<u>3.2</u>	<u>C1-End.....</u>	<u>7</u>
3.2.1	Program depending settings.....	7
3.2.2	Menu settings	7
3.2.3	System-sketch	8
<u>3.3</u>	<u>Reference-Timer.....</u>	<u>9</u>

1 Keyboard

The Timy has a water-resistant silicone-keyboard. This keyboard is perfect for outdoor use. The keys are as big as the small device allows it and they have a perfect pressure-feeling.

 **Function keys:** Depending on the program these keys have different functions. The function is always described above the key in the LCD-screen.





START/ON: This key is used for manual start impulses and to turn on your Timy.



STOP/OFF: This key is used for manual stop impulses and to turn off your Timy.



Printer: This button is as paper feed button (only for model P and PXE). With the button  and  you get into the printer menu.




2nd: This button enables the 2nd function of many other keys.



Menu: With this button you get into the main-menu



CLEAR: Key to clear. Depending on the program you are using you need additional to the  key the red or green OK button to clear the desired time.



Cursor: With the cursor keys you can navigate through the menu.



Green OK: Mainly used to confirm the start numbers for the start side. But you can also confirm any menu functions with this button.



Green OK: Mainly used to confirm the start numbers for the finish side. But you can also confirm any menu functions with this button.

2 Getting started

2.1 Turn ON-OFF

2.1.1 Turn on

- ☞ press the START-button, on the display appears „Really turn on?“
- ☞ press the green OK-button within 10 seconds, otherwise the Timy will switch off automatically.
- ☞ Choose with the cursor buttons the desired program and confirm with OK. Depending on the used program you have to follow the menu. See manual for your program.



2.1.2 Turn off

You can turn off your Timy in 2 ways.

Way 1:

- ☞ press the STOP-key for about 5 seconds, on the display appears "Really turn off?"
- ☞ press the red OK-button within 10 seconds, otherwise the Timy will switch back to the program-mode.



☞

Way 2:

- ☞ press the 2nd key and the STOP-key, on the display appears "Really turn off?"
- ☞ press the red OK-button within 10 seconds, otherwise the Timy will switch back to the program-mode.



2.2 Menu

All standard menu settings are described in the general manual of the Timy. Please refer to the general Timy manual!

3 Programs

Any Timy has various Software as standard included. Whenever you update your Timy all the programs will be updated with the most modern technology.

You can download from our website www.alge-timing.com any manuals you like.

Under the main-program training you can find 3 different special programs

- ☞ **Impuls-counter** will finish the run after a desired amount of impulses.
- ☞ **C1-End** will finish the run as it receive an impulse on channel C1(stop)
- ☞ **Reference-timer** is a very complex program which allows several intermediate-times, multiple athletes on the track and automatic removal of wrong impulses.

3.1 *Impulse-Counter*

This program is developed for training with several measuring-points on one single channel.


3.1.1 Program depending settings

After you have chose this program you have to follow the menu as described below.



3.1.1.1 Amount of impulses

Enter the amount of measuring-points, excluding the start!

3.1.1.2 Delete Memory ?

Press one of the OK-buttons to keep the memory or press  to delete the Memory.

3.1.1.3 Synchronization

With the button  you can change the internal clock, any OK or the button  will advice the Timy to synchronize at the minute change of the internal clock.


3.1.1.4 IMPORTANT!

To prevent your training session from wrong impulses adjust the delay-time to a value which is OK for your sport! See also the general manual!

3.1.2 System-sketch

Depending on the Sport you want to use your Timy the peripheral devices can vary. In the following we will show you some possible system-setups for different sports.

3.1.2.1 ATHLETICS



3.1.2.2 Operating

3.2 C1-End


3.2.1 Program depending settings

After you have chose this program you have to follow the menu as described below.



3.2.1.1 Amount of impulses

Enter the amount of measuring-points, excluding the start!

3.2.1.2 Delete Memory ?

Press one of the OK-buttons to keep the memory or press  to delete the Memory.

3.2.1.3 Synchronization

With the button  you can change the internal clock, any OK or the button  will advice the Timy to synchronize at the minute change of the internal clock.

3.2.1.4 IMPORTANT!

To prevent your training session from wrong impulses adjust the delay-time to a value which is OK for your sport! See also the general manual!

3.2.2 Menu settings


3.2.2.1 STN-Counting

This menu can be found in the general menu and is

3.2.3 System-sketch

Depending on the Sport you want to use your Timy the peripheral devices can vary. In the following we will show you some possible system-setups for different sports.

3.2.3.1 Alpine skiing



3.2.3.2 Bedienung

3.3 *Reference-Timer*

This Program is still in development!